

DROPSHOT™ CARE AND CLEANING GUIDE



DRS-120 in Stainless Steel



DRS-120 in Black Powder Coat

!!! IMPORTANT !!!

**DO NOT MIX CLEANING SOLUTIONS.
ALWAYS READ CLEANING PRODUCT
LABELS FOR PROPER USE.**

Note: The information in this document applies to all DropSpot™ models.

STAINLESS STEEL SURFACES

General, everyday cleaning

To clean unit daily or as often as needed, apply a stainless steel cleaner/polish to a clean, soft sponge or a microfiber cloth and wipe in the direction of the grain. Follow cleaner manufacturer's instructions.

Alternatively, apply a mixture of clean water and a mild dish detergent to a clean, soft sponge or microfiber cloth and wipe in the direction of the grain. For best results, always wipe completely dry with a separate clean, soft microfiber cloth.

DO NOT apply cleaner directly to the unit surfaces; apply the cleaner to the microfiber cloth to clean.

To remove stubborn water marks or minor scratches

Apply a stainless steel cleaner/polish to a soft sponge or microfiber cloth and carefully rub the panel with the grain. ALWAYS RUB IN THE DIRECTION OF THE GRAIN.

To disinfect

Use a solution of clean water and rubbing alcohol. Spray solution onto a soft cloth and wipe down the stainless steel surfaces only. Wipe completely dry with a separate clean, dry cloth. Be sure to always wipe or rub in the direction of the grain to maintain the finish.

To remove rust stains

Should rust stains appear, apply a stainless steel cleaner/polish to a soft sponge or microfiber cloth. If the stainless steel cleaner does not work, then apply vinegar, or a baking soda and water solution to a soft sponge or microfiber cloth. ALWAYS RUB IN THE DIRECTION OF THE GRAIN. Wipe with a soft cloth dampened with clean water and then wipe completely dry with a separate clean, dry microfiber cloth.

DO NOT USE

- Harsh, ammonia or acid based chemicals
- Abrasive, petroleum based cleaners
- Abrasive sponges or brushes, including Scotch-Brite™ or steel wool
- ZEP Spirit II
- 3M™ Quat disinfectant

The information contained in this document is subject to change without notice.

BLACK POWDER COATED SURFACES

General, everyday cleaning

Use only a mixture of clean water and a mild dish soap to clean unit daily or as often as needed. For best results, always rinse well with fresh water and wipe completely dry with a clean, soft, microfiber cloth.

DO NOT apply cleaner directly to the unit surfaces; apply the cleaner to the microfiber cloth to clean.

DO NOT USE

- Harsh, ammonia or acid based chemicals
- Abrasive, petroleum based cleaners
- Abrasive sponges or brushes, including Scotch-Brite™ or steel wool
- ZEP Spirit II
- 3M™ Quat disinfectant
- Sodium hydroxide
- Methanol, ethanol, and Isopropyl (rubbing alcohol) solutions

PLASTIC AND RUBBER COMPONENTS

General, everyday cleaning

The bubbler, push bar, and bottle filler alcove are made of antimicrobial material, prohibiting the growth of microorganisms. Use only a mixture of clean water and a mild detergent to clean unit daily or as often as needed. For best results, always rinse well with fresh water and wipe completely dry with a clean, soft, microfiber cloth.

DO NOT apply cleaner directly to the unit surfaces; apply the cleaner to the microfiber cloth to clean.

**When assistance is required, please contact Sloan
Technical Support at 1.888.SLOAN.14 or 1.888.756.2614.**

The brands and/or products names referenced herein may be subject to trademark rights of their respective owners.

Use of the brands and names is for identification purposes only and does not imply affiliation with or endorsement by Sloan.

SLOAN • 10500 SEYMOUR AVENUE • FRANKLIN PARK, IL 60131

Phone: +1.800.9.VALVE.9 or +1.800.982.5839 • Fax: +1.800.447.8329 • www.sloan.com